
CLAMPING INSTRUCTIONS FOR GM, PREFERRED METHOD

With side rails positioned as shown attach clamps and plastic shims to the side rails at the locations



CLAMPING INSTRUCTIONS FOR GM, PREFERRED METHOD

Disassemble stake pocket clamp assemblies by unscrewing the stake pocket clamp half from the female clamp half.


Item	Part #	Description
4.	1700428	VMI Flat Washer, 5/16"
5.	1703548	Cap Screw, 5/16"
6.	1704576	Stake Pocket Clamp
7.	1704583	Male Clamp
8.	1704585	Urethane Round
(1704592 Assembled Clamp)		
		·

Insert stake pocket clamp half into stake pocket. Pull up slightly on bed cap cover to allow clamp to slip between plastic stake pocket and metal side rail. While holding stake pocket clamp half, insert male clamp half and bolt through the bolt hole of the stake pocket. Insert plastic shim in clamping location. Bolt clamp halfs together and tighten.

CAUTION

Tighten clamp assemblies securely on side rails before driving vehicle. Torque all clamp bolts to 8 FT Lbs. +/-1

NOTE: Over torquing bolts may damage bed rail.



View showing stake pocket clamp correctly attached to the driver side rail and truck box.


tomer sevice for information

regarding shim kit 1117097.

View showing stake pocket clamp correctly attached to the passenger side rail and truck box.

CLAMPING INSTRUCTIONS FOR GM, SECONDARY METHOD

With side rails positioned as shown attach clamps and plastic shims to the side rails at the locations shown. Refer to detail A and B for plastic shim placements.



See front page for Detail "A" & "B" for clamping information.