

Bug Deflector Install Guide

(02-08) Ram

Contents:

(1) Bug Deflector (4) Push Clips
(4) Rubber Bumpers (1) Prep Pad

**Step 1//**

Locate the (4) pre-existing holes on the factory grille. Align the bug deflector and install the (4) supplied plastic push clips.

**Step 2//**

Finish the installation by installing the supplied rubber bumpers to protect the paint anywhere the Bug Deflector may make contact with the hood.

