

# Bug Deflector Install Guide

## (09-18) Ram

### Contents:

- |                    |                    |
|--------------------|--------------------|
| (1) Bug Deflector  | (2) Well Nuts      |
| (2) Machine Screws | (4) Rubber Bumpers |
| (2) Push Clips     | (1) Prep Pad       |

### Tools Required:

- Phillips Head Screw Driver



### Step 1//

The Bug Deflector will be secured to the vehicle using (2) well nuts and screws and (2) plastic push pins. Open the hood and center the Bug Deflector to the hood. This will allow you to identify which of the (4) factory holes are used.



### Step 2//

The outer holes will receive the well nuts. Press the well nuts into the factory holes. If the holes are slightly oversized, use tape to hold well nut in place. \*\*Note: If tape is used the hole in the well nut needs to remain open.



### Step 3//

The inner holes will receive the plastic push clips. If the holes do not initially line up, gently manipulate the Bug Deflector until they do.



### Step 4//

Finish the installation by installing the supplied rubber bumpers to protect the paint anywhere the Bug Deflector may make contact with the hood.