

# **BILLET GRILLE INSTRUCTIONS**

**PN#: R109968/R109966**

**02-07 DODGE RAM1500 UPPER OVERLAY(4 PC)**

## **Hardware**

16-- Bolts                      16-- Nuts                      16-- Flat tabs

NOTE: Be Careful not to scratch the grills Surface.

- (1) Screw bolts inside the hole behind of billet grille.
- (2) Insert billet grille from front on the opening of factory shell.
- (3) Push bolt past through honey comb of factory grille.
- (4) Put spacer provided behind factory honey comb and screw nut on the bolt after spacer.
- (5) Repeat step 4 above for each bolt of the billet grilles on the face of your factory shell.
- (6) Adjust bolt position to make sure the grille is in the center of opening.
- (7) Tighten but be careful of over-tighten.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!