

BILLET GRILLE INSTRUCTIONS

PN#: R109967/R109969

06-08 DODGE RAM UPPER OVERLAY (4PC)

Hardware

16-- Bolts 16-- Nuts 16-- Brackets 16-- Flat Washers

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove the grille shell from the vehicle.
- (2) Take out the factory billet grille and hardware from the package. You must be care of doing this for protect the surface of the factory grille. Because the surface is polished.
- (3) First you should place the bolts through the holes of the tabs welded to the rear of the billet insert, then center the factory grille into the opening. Fasten the grille use the nylon nuts and washers from the rear, but do not tight.
- (4) The installation of the other insert as (3).
- (5) Be sure all insert is centered. Tighten all the hardware, but do not over-tight. And re-install the grille shell.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!