



S111090-S111095
S508962-S508967

Installation Instructions

2007-2018 1500.2500.3500 Ext – Cab & Crew – Cab Exclude Diesel Model

6	T-Bolts	12	M8 clip nuts
3	Driver Mounting Brackets (D)	12	M8 Flange Hex Head Bolts
3	Passenger Mounting Brackets (P)	6	M8 nuts

READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE BEGINNING THE INSTALLATION. WEAR SAFETY GLASSES AND USE ALL SAFETY PRECAUTIONS DURING THE INSTALLATION.

NOTE: REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.

May use the plastics retainers for holding the T-Bolts.

And must remove before tighten the bracket.

(Loosely attach all components prior to fully tightening all bolts)



1. Remove the plastic cover.



2. Insert the M8 clip nuts into the position.



3

3. Align the Passenger bracket then mount with M8 Flange hex bolt. (Do not tighten at this time)



4

4. The front bracket mounting place locate is closed to the front wheel (see step #3).



5

5. Align the side step bar to the bracket and mounting with M8 flange hex bolt.

6. Check all the parts in the right position and tighten the bolts

7. Repeat the step one to six for driver side installations.