

Bug Deflector Install Guide

(16-18) Silverado

Contents:

(1) Bug Deflector (6) Push Clips
 (4) Rubber Bumpers (4) Clear Vinyl Squares
 (1) Prep Pad

Tools Required:

-Phillips Head Screw Driver
 -Flat Head Screw Driver



Step 1//

Open hood and center the Bug Deflector to the hood. This will allow you to identify which of the (6) factory push pins need to be removed. ****Note:** the factory push pins will not be reused.



Step 2//

Using a panel removal tool or a flat head screw driver, remove those (6) push pins.



Step 3//

Once the factory push pins are removed, sandwich the bug deflector between the weather-stripping and the hood. Install the supplied push pins. ****Note:** These are a tight fit and will require you to apply firm pressure on the supplied push pin to insure they are pin catches the weather stripping, Bug Deflector, and the hood.



Step 4//

Finish the installation by installing the supplied rubber bumpers to protect the paint anywhere the Bug Deflector may make contact with the hood.