

BILLET GRILLE INSTRUCTIONS

PN: S112439/ S112441

03-06 CHEVY SILVERADO SS BUMPER SIDE GRILLE (2PC)

Hardware

6 -- Screws 6 -- Flat Nuts

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove the plastic inserts in the bumper cover. They are held in place with plastic rivet type fasteners.
- (2) Match the inserts to the right and left opening (they will only fit one way). Center one of the inserts in the vent opening (it may be necessary to slightly bend the brackets so the insert fits properly. Mark the holes from the mounting tabs onto the vent opening. Repeat on the other side. From the rear of the bumper cover. drill a 1/8" hole at each mounting tab.
- (3) Secure the billet inserts using the fasteners provided. Make sure the billet inserts are correctly aligned.
- (4) Installation is now complete.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!