

# **BILLET GRILLE INSTRUCTIONS**

**PN: S112438/ S112440**

**99-02 Chevy Silverado 1500 /00-06 Chevy Suburban Only For Z71 And With Round Fog Lamps/00-06 Chevy Tahoe Only For Z71 And With Round Fog Lamps Tow Hook(2PCS)**

## **Hardware**

4 -- Phillip Screws                      4 -- Flat Nuts

**NOTE:** Be Careful not to scratch the grills Surface.

- (1) Remove the factory tow hooks.
- (2) Place the billet insert in the air dam opening. Center the insert and mark each hole in the two brackets on each end of the billet. Drill a 3/16" hole at each mark. Align the brackets to the holes in the air dam; insert a screw at each bracket and a clip from the rear of the air dam. Tighten the screws.
- (3) Installation is now complete.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!