

BILLET GRILLE INSTRUCTIONS

PN: S112442/ S112443

03-06 CHEVY SILVERADO TOW HOOK (2PC)

Hardware

6 -- Truss Head Tapping Screws 6 -- "K" Nuts

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove the factory tow hooks. Identify the left and right bumper inserts. Test fit the billets into the openings.
- (2) Hold the billets in place and mark the bracket hole to the openings. Drill a 1/8" hole at each mark. Secure the billets using the screws and nuts provided. Make sure the billets are centered and tighten the fasteners.
- (3) Installation is now complete.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!