

BILLET GRILLE INSTRUCTIONS

PN: S112450/ S112454

99-02 CHEVY SILVERADO 1500 UPPER, OVERLAY (2PCS)

00-06 CHEVY SUBURBAN/TAHOE UPPER, OVERLAY (2PCS)

Hardware

4-- Tabs

4--Screws

4--"U" Clip Nuts

NOTE: Be Careful not to scratch the grills Surface.

1. Remove the plastic filler panel from the top of the radiator support.
2. Remove grilles from box and test fit the grilles first to identify the top grille from the bottom grille. They will only fit in one direction correctly.
3. Remove the flat tabs with the single hole from the installation kit. Place a U-clip nut over the hole on each of the four tabs.
4. Set the top billet grille in the top of factory grille; be sure to place it in the center of the shell.
5. Place a Phillips head screw in each of the two welded tabs of the billet grille place a tab behind the grille shell in line with were the screw comes through. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. **DO NOT OVER TIGHTEN SCREWS.**
6. Repeat steps 3 and 4 for the bottom grille.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!