

## **BILLET GRILLE INSTRUCTIONS**

**PN: S112451/ S112455**

**02-06 Chevy Avalanche Without Body Cladding/03-05 Chevy Silverado 1500 /03-05 Chevy Silverado 1500 SS /03-04 Chevy Silverado 2500 /03-04 Chevy Silverado 3500 /03-05 Chevy Silverado 1500 HD /03-04 Chevy Silverado 2500 HD(2PC)**

**Hardware:**

8-- round-head screws    8-- kept nuts    8--tabs

**NOTE:** Be Careful not to scratch the grills Surface.

- (1)Open the vehicle hood, be sure your hardware can reach to grille shell back.
- (2)Set the billet grille onto factory grille shell, be sure to place it in the center of the shell.
- (3)Place round-head screw in each of the four welded tabs of the billet grille , place tab from behind the grille shell in line with were the screw comes through and attach tabs and nuts Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. DO NOT OVER TIGHTEN SCREWS.
- (4)Repeat steps 3 and 4 for the bottom grille.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!