

BILLET GRILLE INSTRUCTIONS

PN: S112453/ S112457

07-13 CHEVY SILVERADO 1500 UPPER (2PC)

Hardware

10--nuts 10-- flat tabs 10--screws

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove grilles from the box and identify the top grille from the bottom grille.
- (2) Place screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each screw.
- (3) Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the toggle nut past the factory grille honeycomb.
- (4) Turn the toggle nut so that it is vertical, and tighten. But not over-tighten!
- (5) Repeat steps two and four for the remaining four welded tabs on the billet grille.
- (6) Install the lower grille using the same steps as above.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!