

# BILLET GRILLE INSTRUCTIONS

**PN: S112458/ S112459**

**07-09 CHEVY SILVERADO 1500 BUMPER(1PC)**

## **Hardware**

4-- Slotted Studs                      4-- Nuts                      4-- Flat tabs

**NOTE:** Be Careful not to scratch the grills Surface.

- (1) Insert billet grille into the opening bumper of valance to test it fitment.
- (2) Remove the grille shell from the vehicle.
- (3) Insert the screws to the billet grille tabs and then put the billet grille into your opening bumper holes and then make the screws through the rear of grille shell
- (4) Place flat tab into stud and tight it with nut.

Repeat above step4 for other stud and nuts, then install grille shell on the vehicle, complete installation now.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!