

# **BILLET GRILLE INSTRUCTIONS**

**PN: S112462/ S112464**

**03-06 CHEVY SILVERADO SS CENTER BUMPER (1PC)**

## **Hardware**

-- do not need any hardware

**NOTE:** Be Careful not to scratch the grills Surface.

- (1) Remove the plastic insert in the center of the bumper cover. It is held in the opening with plastic rivet type fasteners. Do not discard these fasteners.
- (2) Center the insert in the bumper opening. Align the tabs on the insert to the factory mounting holes. Secure the billet insert using the factory fasteners (not all of them are needed).
- (3) Installation is now complete.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!