



**Read complete instructions
before installation!
Improper installation may
void warranty**

Tools Needed
Torx bit set
3/8 Ratchet



Start by opening your tailgate.



Remove the 2 Torx screw holding
the taillight in.



Remove your stock sockets from
the back of the light.



Once you have removed the sockets
from the housing. Remove the bulbs
from the sockets. Leave the reverse
bulb alone.



Next plug the connectors into your
stock socket. Be sure to line
the black wire up on the same
side on both the socket
and connector.

Twist your connectors into the new
housing and reinstall the
taillight back on the vehicle the
same way you removed it.



Test all functions of the light
before driving on public
highways.