



S111090-S111095  
S508962-S508967

# Installation Instructions

## 2007-2018 1500.2500.3500 Ext – Cab & Crew – Cab Exclude Diesel Model

6	T-Bolts	12	M8 clip nuts
3	Driver Mounting Brackets (D)	12	M8 Flange Hex Head Bolts
3	Passenger Mounting Brackets (P)	6	M8 nuts

READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE BEGINNING THE INSTALLATION. WEAR SAFETY GLASSES AND USE ALL SAFETY PRECAUTIONS DURING THE INSTALLATION.

**NOTE: REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.**

**May use the plastics retainers for holding the T-Bolts.**

**And must remove before tighten the bracket.**

**(Loosely attach all components prior to fully tightening all bolts)**



1. Remove the plastic cover.



2. Insert the M8 clip nuts into the position.



3

3. Align the Passenger bracket then mount with M8 Flange hex bolt. (Do not tighten at this time)



4

4. The front bracket mounting place locate is closed to the front wheel (see step #3).



5

5. Align the side step bar to the bracket and mounting with M8 flange hex bolt.

**6. Check all the parts in the right position and tighten the bolts**

7. Repeat the step one to six for driver side installations.