

# Bug Deflector Install Guide

(07-13) Sierra

## Contents:

(1) Bug Deflector      (4) Well Nuts  
 (4) Machine Screws    (4) Rubber Bumpers  
 (1) Prep Pad

## Tools Required:

-Phillips Head Screw Driver



### Step 1//

The Bug Deflector will be secured to the vehicle using (4) well nuts with (4) screws. Open the hood and center the Bug Deflector to the hood. This will allow you to identify which of the (4) factory holes receive the rubber well nuts.



### Step 2//

Press the well nuts into the factory holes. If the holes are slightly oversized, use tape to hold well nut in place. **\*\*Note:** If tape is used the hole in the well nut needs to remain open.



### Step 3//

Hold the Bug Deflector up to the hood. Tighten the supplied screws into the well nuts. **\*\*Note:** if the well nut doesn't tighten, you may need to apply firm pressure on the Bug Deflector to prevent the well nut from spinning in the hole. Once the well nut tightens up it will stop spinning in place.



### Step 4//

Finish the installation by installing the supplied rubber bumpers to protect the paint anywhere the Bug Deflector may make contact with the hood.