

Contents:

- (1) - Shock
- (1) - Upper Ball Mount Plate - 10mm Wrench/Socket
- (1) - Lower Ball Mount Plate
- (1) - Torx Wrench

Required:

- Flat Screw Driver

****Note:**

Install on Driver Side only.



Step 2

Install the upper bracket behind the upper lift gate bolt. Reinstall lift gate strap.



Step 4

Install the lower ball mount plate, reuse the factory bolts.



Step 1

Remove the lift gate strap and loosen the T50 lift gate bolt.



Step 3

Remove the (2) 10mm bolts on the lower tailgate bracket.



Step 5

Install shock as shown above.