



Contents:

- | | |
|--------------------------------|--------------------------|
| ((1) Driver Side Front Flare | (4) LED Light Screws |
| (1) Driver Side Rear Flare | (1) Rubber Edge Trim Kit |
| (1) Passenger Side Front Flare | (8) Long Speed Clips |
| (1) Passenger Side Rear Flare | (6) L Mounting Brackets |
| (2) LED Lights | (8) 8mm x 3/4 screws |
| (1) LED Light Harnesses | (10) 8mm x 1/2 screws |

Barricade Raptor Style Fender Flares (15-17 F150)

TOOLS REQUIRED:

Phillips Screw Driver
5.5mm, 10mm Sockets
Ratchet
Utility Knife

Note:

Vehicles equipped with factory fender flares must be removed prior to installation. New Barricade Flares are marked (D) for Driverside, and (P) for Passenger side. Front Flares have marker lights.



STEP 1 // Begin by installing the supplied rubber edge trim onto each fender flare where the flare meets the body of the vehicle. Peel back approx 2" of the red lining, and push the rubber trim onto the edge of the flare that meets the body of the vehicle. Then completely pull the red backing off and firmly press the trim to bond to the flare. Cut the trim to length. ****Note**, rubber trim covers end to end.



STEP 3 // If your vehicle is equipped with factory fender flares and mud flaps they must be removed before installation of the Barricade flares.



STEP 2 // Install the LED marker light to the flare. Insert the two wires through the center hole, and secure the light to the flare using the (2) 8mm x 1/2 screws.



STEP 4 // **Front Fender Flares:** Locate, and remove the factory (7) 5.5mm screws. ****Note** factory screws will be reused.



STEP 5 // Install the (3) mounting brackets to the wheel well using the factory screws. ****Note**, do not fully tighten the screws.



STEP 8 // Install the supplied wiring harness to the marker light on each fender flare and tap the Red 12v + wire and Black - wire into the driver side marker light harness.



STEP 6 // Attach the front fender flare marked (D) to the mounting brackets using the (3) 8mm x 1/2 screws. ****Note**, leave the wires for the marker light facing out from the fender flare.



STEP 9 // **Rear Fender Flares:** With a helper, hold the rear fender flare marked (D) tight against the wheel well. Using painters tape, mark the locations on the lip of the wheel well where the body clips are going to mount by matching up with the holes of the fender flare.



STEP 7 // While pushing the flare flush against the wheel well, install the (2) factory screws in the front, and the (2) factory screws on the rear to secure the flare to the vehicle. ****Note**, fully tighten the mounting brackets from Step 5 once the flare is fully flush against the body of the vehicle.



STEP 10 // Insert the (4) body clips on the lip of the wheel well over the tapped locations from the inside out. ****Note** If you have factory flares, clips will not line up with the factory holes.



STEP 11 // Lay the fender flare against the wheel well, from the bottom up insert the (1) push pin securing the bottom of the flare to the vehicle.



STEP 12 // Install the fender flare to the wheel well body clips using the (4) 8mm x 3/4 screws. Do not over-tighten. Installation is now complete. **Note, push in on the fender flare where needed to reduce fender gaps.