



INSTALLATION INSTRUCTIONS

AUTOMOTIVE PRODUCTS,

APPLICATION:

2009-2014 Ford F-150

PART NUMBER:

58-240905/58-24090R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	2	TAG LIGHTS	10MM SOCKET
2	4	1/2" X 1 1/2" BOLT	21MM SOCKET
3	4	1/2" NUT	3/4" SOCKET
			3/4" WRENCH
			RATCHET
REMOVAL			
<ol style="list-style-type: none"> 1. Disconnect the tag lights 2. Remove the 6 bolts that hold the bumper to the receiver hitch 3. Remove the bumper from the truck 4. Remove the bolt plate that holds the receiver to the frame 			
INSTALLATION			
<ol style="list-style-type: none"> 1. Install the tag light in bumper 2. Install the frame brackets using the factory bolt plates 3. Align the bumper with the intermediate brackets using the 4 - 1/2" x 1 1/2" bolts and 1/2" nuts 4. Adjust the bumper to achieve proper alignment 5. Tighten all hardware 6. Splice the tag lights to the factory harness with the red wire going to the positive factory wire 			



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773