

# SPEEDIFORM

## Installation Instructions for Tailgate Insert Letters (18+ F-150)

### Contents:

- (1) Insert Letters
- (2) Alcohol Prep Pads

### Tools:

- Clean Towel
- Soap & Water



### Step 1:

Using soap and water, thoroughly clean the tailgate to remove any dirt. Allow the tailgate time to dry. Once tailgate is dry, use the supplied (2) alcohol prep pads to clean the area where the letters will be applied.



### Step 2:

Before removing the tape backing, test fit the part on the vehicle to familiarize yourself with how it fits. Then remove the tape backing and install the part.



### Step 3:

Apply firm even pressure to the tape surfaces to ensure proper adhesion.