

Smoked LED Fender Lights - Front 2010-2019 Raptor

Contents:
(2) Smoked LED Fender Lights

Tools Required:
-Trim Panel Removal Tool
-5.5mm Socket and Ratchet



Step 1
Using a trim panel removal tool, remove the (1) push clip on the fender flare, and (1) push clip on the inner fender liner. Then remove the (1) 5.5mm screw on the inner fender liner.



Step 2
Carefully pull back on the inner fender liner to gain access to the fender light harness. Unplug the light from the harness.



Step 3
Carefully pull out the fender light from the rubber grommet.



Step 4
Remove the rubber grommet from the body of the fender, and carefully pull the light and harness from the fender.



Step 5
Carefully remove the factory rubber grommet from the factory light and harness. Transfer the rubber grommet to the new light.



Step 6
Install the new light by reversing Steps 1-4. Repeat steps for opposite side. Installation is now complete.