

Tailgate Assist

15-18 F150

Contents:

- (1) - Shock
- (1) - Upper Ball Mount Plate - 10mm Wrench/Socket
- (1) - Lower Ball Mount Plate
- (1) - Torx Wrench

Required:

- Flat Screw Driver

**Note:

Install on Driver Side only.



Step 2\\

Install the upper bracket behind the upper lift gate bolt. Reinstall lift gate strap.



Step 4\\

Install the lower ball mount plate, reuse the factory bolts.



Step 1\\

Remove the lift gate strap and loosen the T50 lift gate bolt.



Step 3\\

Remove the (2) 10mm bolts on the lower tailgate bracket.



Step 5\\

Install shock as shown above.