


Intake Kit Installation Instructions: 2009-2012 Dodge Ram 1500, V8-5.7L Hemi




advanced FLOW engineering™  
P.O. Box 1719  
Corona, CA 92878  
Support: 951-493-7100  
aFepower.com

Kit Part #	51/54-11632 Stage 2	Tools Required:	Part List:	
Make:	Dodge	5/16" nut driver or slotted screwdriver	1 Air filter <i>Pro-5R</i> ™ 24-91040 or	1 Coupling, 15deg elbow (05-00816)
Model	Year	4mm Allen Wrench	<i>Pro Dry S</i> ™ 21-90053	1 Coupling, 40deg elbow (05-00464)
Ram 1500	2009-2012	Engine	1 Air filter adapter	3 Clamps #056
			5 M6x10 button head bolts	1 Clamp #064
			1 Tube, intake	
			1 Housing	
			1 Grommet	
			1 Rubber hose 36"	
			1 Trim-seal 29.25"	



Complete stock intake.




Loosen the clamp at the throttle body.



Disconnect the tempature sensor by sliding back the red clip, then pushing the black release tab and pulling off.



Unplug the crank case breather tube.



Unclip all four clips on the stock air box.




Pull up on the stock intake tube to remove it from the throttle body.




Lift off the stock air box cover and tube.



Remove the stock air filter.




Secure the air filter adapter to the housing using the (5) M6 allen bolts provided. Then place filter onto filter adapter and tighten the clamp.



Place aFe housing and filter into the stock OEM Airbox and clip all four clips to secure housing.




Remove the engine cover by pulling up on one side at a time to pop it loose. Install the 15deg elbow coupling on the throttle body and leave the clamps loose.



Twist the crank case breather line and pull it directly up to remove.



Replace old crank case breather line with the hose provided and run in direction of the OEM line and put the engine cover back on. Remember that the engine cover has a slot where this line will come out from.



Place the 40 deg velbow coupling onto the adapter but do not tighten clamp until later.



zRemove the temperature sensor from the stock intake tube. Use a rag to help pull the sensor straight out. The sensor is plasic so take your time and be careful when removing.


**Note:** Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, aFe P/N: 90-50501 blue squeeze bottle oil, or aFe P/N: 90-59999 Pro-Dry S Cleaner)  
Filter Replacement: Magnum FLOW P/N: **Pro-5R**™#24-91040 (black w/blue media) or **Pro Dry S**™#21-90053 (black w/white media)

Intake Kit Installation Instructions: 2009-2012 Dodge Ram 1500, V8-5.7L Hemi



advanced FLOW engineering™  
P.O. Box 1719  
Corona, CA 92878  
Support: 951-493-7100  
aFepower.com

Kit Part #51/54-11632 Stage 2			Tools Required:	Part List:	
			5/16” nut driver or slotted screwdriver	1 Air filter <i>Pro-5R</i> ™ 24-91040 or	1 Coupling, 15deg elbow (05-00816)
Make: Dodge			4mm Allen Wrench	<i>Pro Dry S</i> ™ 21-90053	1 Coupling, 60deg elbow (05-00464)
ModelYearEngine				1 Air filter adapter	3 Clamps #056
Ram 15002009-2012V8-5.7L Hemi				5 M6x10 button head bolts	1 Clamp #064
				1 Tube, intake	
				1 Housing	
				1 Grommet	
				1 Rubber hose 36”	
				1 Trim-seal 29.25”	



Place the provided grommet into the hole on your new aFe intake tube. **Note: Tube finish may vary from photos.**




Install your tempature sensor into the grommet.



Place intake tube into the couplings and make sure the elbow coupler is in the correct position and is not kinked before tightening all clamps.



Plug in the supplied crank case breather hose to the intake tube nipple.



Reinstall your tempature sensor plug and press the red tab back to lock it into position.



Your install is complete. Make sure all clamps are tight and all electrical connections are secure. Retighten all clamps after a few hours of use.  
Thank you for choosing aFePower.

**Note:** Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, aFe P/N: 90-50501 blue squeeze bottle oil, or aFe P/N: 90-59999 Pro-Dry S Cleaner)  
Filter Replacement: Magnum FLOW P/N: **Pro-5R**™#24-91040 (black w/blue media) or **Pro Dry S**™#21-90053 (black w/white media)