IMPORTANT: PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE



2009-11 Dodge Ram Stainless Steel "Q" & Mesh Grilles




4 Piece Heavy Mesh Grille Part # 1117-0104-09

<u>Quantity</u>	<u>Description</u>	<u>Part No.</u>
1 Upper 1 Upper 1 Upper 1 Upper 2 Upper 2 Upper 1 Hardw (16)1.0	Upper Left Mesh Surround Upper Right Mesh Surround Lower Left Mesh Surround Lower Right Mesh Surround Upper Mesh Sections Lower Mesh Sections Lower Mesh Sections Vare Kit (components listed below) Upper Mesh Sections Vare Kit (components listed below) Upper Mesh Sections Upper Mesh Surround Upper Right Mesh Surround Upper Mesh Surround Upper Mesh Sections Uppe	

4 Piece "Q" Grille Part # 1117-0185-09Q

<u>Quantity</u>	<u>Description</u>	<u>Part No.</u>
1 Upper 1 Upper 1 Upper 1 Hardw (16)1.0	Upper Left "Q" Section Upper Right "Q" Section Lower Left "Q" Section Lower Right "Q" Section vare Kit (components listed belo 06" x.189" x.064" Black Plastic Wa 8-32 ESNA Half Nuts	1117-018A-09Q 1117-018D-09Q 1117-018C09Q ow) _ 1117-1902-09 shers 1999-0264-00

PLEASE HANDLE WITH CARE! THE EDGES OF THE STAINLESS STEEL MESH & GRILLE MAY BE SHARP!




 Open the hood and remove the radiator support panel cover exposing the factory hardware retaining the grille. Remove the plastic push pins by pulling straight up.

Fine Mesh Bumper Insert Part # 1117-010L-09

<u>Quantity</u>	<u>Description</u>	<u>Part No.</u>
1 Bumper In:	sert Surround	1117-0022-09
2 Bumper In:	sert Mesh Sections	1117-0021-09
1 Hardware	Kit (components listed belo	ow)_ 1117-1903-09
	ack Plastic Washers	
	ESNA Half Nuts	
(1) Lower F	Hole Location Template $ _$	1117-0067-00

"Q" Bumper Insert Part # 1117-018L-09Q

<u>Quantity</u>	<u>Description</u>	Part No.
		1117-0183-09Q
1 Hardv	vare Kit (components listed below)_	_ 1117-1903-09
(2) Sm	all Black Plastic Washers	1999-0256-00
(2) #8	3-32 ESNA Half Nuts	1999-0065-00
	1 Hardv (2) Sm (2) #8	 _




- Remove the four (4) 10mm hex bolts securing the top of the factory grille to the radiator support panel.
 Remove the factory grille from the lower mounts by
- Remove the factory grille from the lower mounts by tilting the grille slightly forward while pulling straight out.


Important information before you begin:

This E&G grille installation kit includes grille hole location template(s) to drill mounting holes in the vehicle.


Before marking or drilling any holes into the vehicle, you MUST verify that the template(s) provided in this kit match the mounting pin locations on the grille(s).




 Remove the ends from the supplied black vinyl caps and slide them over the mounting studs on the grille sections (mesh grille shown, "Q" grille same). Align the mesh sections onto the backs of the stainless surrounds.



4. Install the stainless steel E&G grille sections into the openings on the factory grilles and tape them into place. Turn the grille over and install a large black plastic washer and a #8-32 ESNA half nut onto each mounting stud and tighten until snug. DO NOT OVERTIGHTEN or you will indent the grilles at the stud locations (mesh grille shown, "Q" grille same).




5. Reinstall the factory grille by clipping in the lower edge and reinstalling the four (4) 10mm hex head bolts.




6. Reinstall the radiator support panel cover.




Align the lower template into palce and mark the outer hole location using an awl or similar pointed tool. Mark the hole on the opposite side by flipping the template over and aligning it into the opening.



8. Use a 3/8" drill bit to drill through the marks made in the previous step.



9. Align the mesh sections and the lower surround into the opening in the front bumper. Make sure the studs pass through the holes drilled in the previous step (mesh grille shown, "Q" similar).



10. From underneath, install the small black plastic washers and the #8-32 ESNA half nuts and tighten. DO NOT OVERTIGHTEN or you will indent the grille at the stud locations.



11.E&G recommends using a mild solvent to remove any glue residue from the grille surrounds. Use alcohol or glass cleaner to remove any solvent residue.

12.Finished installation.

