

STEP 2 - Edge trim installation

A. Peel two to three inches of red vinyl backing away from Edge Trim tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).

B. Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.



STEP 3 - Edge trim tool procedures

Installation (Left Front Flare Shown)



Use allen key to tight allen bolt ,washer & nut firmly on every pocket of the fender flares first then place the flare on the vehicle with best position. Apply 2 Push-In Clip into the mounting slot in flare and secure it to the vehicle as shown .Fasten the existing factory screws into the original location that were previously removed.

Installation (Left Rear Flare Shown)



Use allen key to tight allen bolt ,washer & nut firmly on ever pocket of the fender flares first , then place the flare on the vehicle with best position. Apply 3 Push-In Clip into the mounting slot in flare and secure it to the vehicle. Apply 2 Plastic Expanding Fastener into the mountin g slot in flare and secure it to the vehicle as shown. Fasten the existing factory screws into the original location that were previously removed.

(Optional B;Use the included self tapping screw to instead of the Expanding Fastener.where the Expanding Fastener is not workable on the different condition of the fenger,or it may be used for extra secure when it's needed.)