

Congratulations on your purchase of a high quality PUTCO product.
Should you need any application or technical assistance feel free to call us at: 1-800-247-3974
Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)
Contact your PUTCO dealer for other quality accessories.

Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.

Parts List

Description	Qty
Diamond Donut (P/N # 175)	2
Foam Gasket	2
9/16" Bolt	2
Flat Washer	2
5/32" Set Screw	2

Tools Needed for Installation

9/16" Socket & Ratchet
5/32" Allen Wrench
7/16" Drill Bit
Drill
Tape Measure

Step 1: Measure from center of stake pocket hole to toolbox, subtract 5/8 inch.

Step 2: Transfer measurements to bed rail, starting at the center of hole in pad.

<<NOTE: MEASURE TWICE, CUT ONCE. >>

Step 3: While holding Diamond Donut at appropriate place on toolbox, mark toolbox with a nail thru the center of donut. Drill 7/16" hole in the toolbox.

Step 4: Place the gasket between donut and the toolbox.

Step 5: Mount both donuts with the set screw facing 4 and 8 positions of a clock.

Step 6: Be sure set screws are not blocking groove.

Step 7: Install bed rails in the donuts and then fasten pads to rear stake pocket holes.

Step 8: Tighten set screws in Diamond Donuts.

Step 9: Verify all hardware is tight to complete the assembly.

