



INSTALLATION INSTRUCTIONS

APPLICATION:

2015 Ford F-150

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-141515/58-14151R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	6	1/2 x 3 1/2 in Bolt	18MM SOCKET
2	8	1/2 x 1 1/2 in Bolt	3/4 in RATCHET
3	14	1/2 in Nuts	TORQUE WRENCH
4	4	M8 - 1.25 X 14 MM CAP SCREW	

REMOVAL

1. Remove the plastic insert from the face of the bumper. (Image 1)
2. Disconnect the factory fog light harness. (If equipped)
3. Remove the push pin clips from the upper valance. (Image 2)
4. Remove the 6 nuts holding the factory bumper to the frame (Image 3)
5. Remove the factory bumper



Image 1



Image 2



Image 3



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846
www.westinautomotive.com

INSTALLATION

1. Loosely attach the frame brackets to the frame using the 8 - 1 1/2 inch bolts and 8 - 1/2 inch nuts (Image 4)
2. Carefully lift the bumper and align the mounts with the slots in the frame brackets. Install the 6 - 3 1/2 inch bolts and 6 - 1/2 inch nuts
3. Adjust the bumper to achieve proper alignment



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773