

Horizon LED Tail Lights (14-17)

Tools Needed:

-Basic Hand Tools

Step 1:

Begin by removing the negative battery terminal. Remove the (2) T15 Torx screws from the factory tail light. Apply firm even pressure towards the back of the truck to unclip the tail light from the fender.



Step 2:

Twist the bulb sockets to remove the tail light harness from the light.



Step 3:

Using a T25 Torx remove the (2) tail light clips from the factory lights. Transfer these to the new tail light using the factory hardware.



Step 4:

Remove the factory tail light bulbs. Insert the Raxiom tail light plugs into the factory bulb locations. **Note: One bulb socket will remain unused. Apply electrical tape to the empty plug to protect it from the elements before reinstalling the light. Reconnect the battery terminal and ensure the tail lights functions properly before reinstall the tail light in reverse order.

