

Thank you for choosing Rough Country for all your suspension needs.

WARNING Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

CAUTION This bracket kit was designed to fit a Rough Country 30" Cree LED light bar.

KIT CONTENTS

(2) Light Brackets Instructions



TOOLS NEEDED T-30 torx bit

INSTALLATION INSTRUCTIONS

- 1. Pop hood. Using a T-30 Torx, remove hood stop mount bolt. See Photo 1.
- 2. Next, place light bracket on hood stop mount. Using factory hardware snug bolt. Repeat process for other side of vehicle. See Photo 2. *Note* Do Not Tighten At This Time.





- Insert light between brackets and and secure with supplied bolts and Allen wrench. See Photo 3. Repeat steps on the driver side.
- 4. Tighten light brackets at hood stop with T-30 Torx, on both sides. Wire light and switch to your liking. See Photo 4.





By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.