



Magnum Force

Intake System Cover

PN 54-12068

Important!

Please read all instruction steps before you begin installation.

Make	Model	Year	Engine
Ford	F-150	2009-2010	V8-4.6L, 5.4L
Ford	F-150	2011-2012	V6-3.7L
Ford	F-150	2011-2012	V8-5.0L, 6.2L
Ford	F-150	2011-2012	V6-3.5L (tt)

Step 1. Remove your aFe intake kit by disconnecting intake tube from adaptor and remove air intake from air box

Step 2. Once on the bench remove trim seal from housing.

Step 3. Remove all (5) M6 screws from adaptor from housing keeping adaptor in place.

Step 4. Place the cover on the housing and install M6 screws back in place.

Step 5. Reinstall housing to air box and attach tube to adaptor.

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com