



2004-08 Ford F150

all models except Harley

Grille Instructions



- 1 In order to install RBP grille you need to remove OEM grille from truck by opening hood and removing factory hardware that is attached to hood on upper trim.
- 2 Cut center of grille out leaving the "edge" between grille shell and center as shown.
- 3 Lay new grille into opening ,Make sure its centered. Press firmly
- 4 After holes are drilled,take the number 10 screws while attaching spring nut to back side and tighten with philips screw driver



FOR TECHNICAL ASSISTANCE CALL
1(800) 237-7560