

2015+ Ford F-150 Full Towing Mirror Cover Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974
Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)
Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty
Drivers Side Tow Mirror Covers	2
Passengers Side Tow Mirror Covers	2

Tools Required:

- Rubbing Alcohol
- Clean Towel

Mirror Cover Installation- Passengers Side Shown

Note: Mirror has been removed from the vehicle for demonstration purposes only and is not required for installation.

1. Clean and dry the vehicle thoroughly.
2. The vehicle surface temperature must be a minimum of 15°C (60°F).
3. Dry fit backside cover onto mirror to verify installation method. **DO NOT peel release liner on 3M tape at this time.**
4. Repeat Step 1 with the front side cover. Both covers should have a thin uniform gap where the two come together. Remove both covers and set aside.
5. Wipe down entire towing mirror surface (front and back) with rubbing alcohol. Figure 1.



Figure 1

6. Starting with the backside cover, peel the release liner from all the 3M tape locations. (6 strips total). Figure 2



Figure 2

7. Carefully Slide the cover onto the mirror with the method used during step 3. Figure 3



Figure 3

8. When aligned, press and hold in position for 30 seconds to ensure proper adhesion.

9. Next Peel the release liner from all the strips of 3M tape on the front side cover. Figure 4



Figure 4

10. Carefully Slide the cover onto the mirror with the method used during step 3. Figure 5



Figure 5

11. When aligned, press and hold in position for 30 seconds around the perimeter of the cover to ensure proper adhesion.

12. Repeat Steps 3-11 for the remaining side. Enjoy!!