

L'HAYON ALLUME LA BARRE TELEGRAPHIANT ET L'INSTALLATION

1 Préparation de pré-installation.

Vérifier les contenus de trousse (le contrôle contre les parties énumérant). Enlever l'emballage protectif des bandes légères ou la trousse de boulon.

2 Attacher l'hayon barre légère au véhicule.

Placer la barre légère au-dessus de la plaque de permis et le centre entre la plaque d'hayon et permis. **Assurer que le « TOP » de mot sur l'hayon barre légère est sur indiquant ascendant.** Marquer de trou montant avec une borne. Obtenir la barre légère au véhicule.

3 Télégraphier l'hayon barre légère dans le système électrique.

Utiliser l'inclus a classé installation électrique par couleurs l'harnais et épisse chaque fil au fil approprié sur les lampes de la queue de votre véhicule. Etre sûr de couvrir chaque épissure avec la bande électrique ou l'autre produit électrique.

LED Fil léger	Le Fil existant de Lampe de Queue
Rouge	Freiner la lumière
Juane	Le signal gauche de virage
Blanc	Sol / Négatif
Vert	Le bon signal de virage
Marron	La journée/courant allume

LA BARRA DE LA LUZ DE LA PUERTA TRASERA QUE ALAMBRA Y LA INSTALACION

1 Preparación de pre-instalación.

Verifique el contenido de juego (cheque contra las partes que listan). Quite cualquier envolver protector de las tiras ligeras o cierre juego.

2 Conecte puerta trasera la barra ligera al vehículo.

Coloque la barra ligera encima de la matrícula y central entre puerta trasera y matrícula. **Cerciórese la "TOP" de palabra en la puerta trasera la barra ligera está a señalar hacia arriba.** Marque hoyos que montan con un marcador. Asegure la barra ligera al vehículo.

3 Alambre puerta trasera la barra ligera en el sistema eléctrico.

Utilice el incluido identificado por colores alambrando arreos y empalma cada alambre al alambre apropiado en sus lámparas de cola de vehículo. Esté seguro cubrir cada empalme con cinta aislante u otro producto eléctrico.

LED Alambre ligero	Alambre de Lámpara de cola
Rojo	Frene la luz
Amarillo	Intermitente izquierdo
Blanco	Suelo / Negativo
Verde	Señal de giro a la derecha
Brown	Correr/luz de estacionamiento

INSTALLATION INSTRUCTIONS

PURE LED 15" MINI TAILGATE LIGHT BAR

SERIES #940015 & #940315



Please note: You must follow these instructions to install the parts correctly otherwise damage may occur.
Read all instructions before installation and check to see if all parts listed are included.

KIT CONTENTS

Item#	Qty	Description
1	1	LED light bar (15")
2	2	Gasket

BOLT KIT CONTENTS

None

RECOMMENDED TOOLS

<i>Safety Tools</i>
1. Eye Protection
<i>Special Tools</i>
1. Electrical tape (if needed)
<i>Installation Tools</i>
1. Screwdriver (Phillips)

LED TAILGATE LIGHT BAR WIRING AND INSTALLATION

1 Pre-installation preparation.

Verify the kit contents (check against parts listing). Remove any protective wrapping from the light strips or bolt kit.

2 Attach LED tailgate light bar to vehicle.

Place the light bar above the license plate and center between tailgate and license plate. **Note: Make sure the word "TOP" on the tailgate light bar is pointing upward.** Mark mounting holes with a marker. Secure the light bar to the vehicle.

3 Wire LED tailgate light bar into electrical system.

Use the included color-coded wiring harness and splice each wire to the appropriate wire on your vehicle's tail lamps. Be sure to cover each splice with electrical tape or other electric product.

LED Light Wire	Existing Tail Lamp Wire
Red	Brake light
Yellow	Left turn signal
White	Ground/negative
Green	Right turn signal
Brown	Running/parking light

Questions? Call Putco's customer service at 1-800-247-3974

Monday – Friday, 8am – 5pm central time

216 West First Street • Story City, IA • 50248

www.putco.com

LIMITED WARRANTY

Putco guarantees its products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. Putco is not liable for any vehicle damage resulting from the installation of our Pure LED Mini Tailgate Light Bars.