

## **Barricade 5" Oval Side Bar 2015 Ford F150 SuperCrew**

**Time Necessary:** Approximately 1 hour

### **Tools Required:**

- 13mm socket
- Ratchet
- 3/8" extension (optional)

### **Installation Procedure:**

1. Separate all screws, washers, and nuts check inventory. The black screws, washers, lock washers are for bracket to sidebar. The brass washers, and lock nuts are for brackets to truck.



2. Remove Sidebars from packaging and layout the brackets



- Put all the black screws, lock nuts, washers together for all 12 to mount brackets to sidebars.



- Install above screws to the bottom of the sidebars with brackets following the curve of the sidebars with 13mm socket (leave loose for adjustments).



5. Install plastic washers onto vehicles factory studs



6. Install sidebars onto studs with washer then locknut (leave loose for adjustments).  
Note: Two closest brackets go towards the front of the vehicle on both sides.







7. Check for level, tighten all nuts using 13mm socket, and enjoy your new sidebars!!



Installation Instructions written by: AmericanMuscle customer Timothy A. Grant 1.28.16