

UnderCover Swing Case Storage (Ram 1500 02-18)

Required Tools

- Drill with 5/32 drill bit
- 7/16 or 11mm socket/wrench
- Pencil or something to mark truck bed with

Included in Box

- Tool box
- Bracket A (taller bracket w/ storage box posts)
- Bracket B (longer skinner bracket with bronze locking mechanism)
- (6) Mounting screws
- (2) Screw nuts
- (2) Keys



Installation Instructions

1. Remove the plastic/rubber covering from the 2 screw post on bracket A and slide bracket B over the 2 screw post using the 2 nuts to secure it together



2. Tighten using the 7/16 wrench until snug



3. A-line the bottom of bracket A about 1 ½ inches above the bottom bed of your truck, with the pegs for the tool box facing upwards
4. Draw marks inside of each of the 6 screw holes
5. Set the bracket aside and drill through the truck bed side wall until you go through for all 6 of your marks
6. Re position the bracket over the holes and screw in the mounting screws, they will require force to get started



7. After all 6 of your mounting screws have been screwed in double check to make sure they are all tight, just be careful not to over tighten and strip the screw
8. Position the holes in the tool box mount over the pegs on bracket A and slide it down



9. Push the tool box toward the side of your truck until the latches are closed and you're done



10. I recommend keeping the tool box locked, as well as putting a padlock in the designated area so that no one can steal your brand new storage box



Installation Instructions Written by AmericanTrucks Customer Garrett Friou on 4/17/18