Roll and Lock Tonneau Cover

Contents:

- (2) Bed Rail Channels
- (1)Roll and Lock Tonneau Cover
- (6) Bed Rail Clamps

Tools Required:

- Allen Wrench
- Phillips Head Screw Driver



Step 1 \\
Place the rails on either side of the bed. Note the orientation of the locking portion of the rails shown.



Space the rail clamps evenly over the distance of the bed of the truck. Tighten the clamps enough so that they are secure but leave them loose enough that you can still slightly move the rail forward/back. **Note: For Vehicles with utility rails see note at end of install.





Step3\\

Slide the Tonneau cover into the rails at the front of the bed. The plastic portion slides into the rail on either side. Use the thumb screw to secure the tonneau cover to the rails.





Step4Position the center bracing into the notches of the side rail. These will be marked (F) front, (M) middle, (R) rear.



Step5\\

Fold the tonneau cover out towards the rear of the vehicle. Note the black plastic portion of the tonneau cover clips into the outer edge of the rail. Secure the tonneau cover the rails working your way towards the back of the vehicle.



Step6\\

Clip the end of the tonneau cover into the locking portion of the rail. Note: You will need to move the rails around so that they are even side-to-side and front-to-back. Once secured, reach under the tonneau cover and tighten the last clamp on either side.

Step7\\

Pull the release to unlock the cover from the rails. Fold the cover back and tighten all remaining clamps. Make sure all set screws are tight on the tonneau cover and

rails.



Step8\\

Remove the center support bracing and secure the tonneau cover using the pre-installed straps when not in use.

Toyota and Nissan Trucks with Factory Utility Rails





Utility Rails

Remove the rail end caps and install the supplied utility rail clamps. There are several different clamp styles depending on the tonneau cover style. Above are (2) different examples.