

FULL TAILGATE GUARD INSTALLATION SHEET

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at:

1-800-247-3974

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time) Contact your PUTCO dealer for other quality accessories. PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION AND BE SURE TO CHECK TO SEE THAT ALL PARTS AND HARDWARE ARE INCLUDED.

- **Step 1:** Open your tailgate and place tailgate protector and plate on the tailgate to check for proper fit, if the protector does not seem to fit properly, call Putco for assistance.
- **NOTE:** The protector and plate should overlap at the top of the tailgate with the plate under the protector. The hole should line up so that one screw goes through the protector and the plate.
- **Step 2:** Remove the protective covering from the surface of your tailgate protector and plate.
- Step 3: Press firmly on the tailgate protector so that it properly seats on the tailgate and using a drill (corded or cordless) and a Phillip's screw bit fasten the tailgate protector to the tailgate with the self-tapping screws provided.

 HINT: Start with one outside mounting hole, then go to the other outside mounting hole and work your way inward.
- Step 4: Put a screw into each of the holes of the plate.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new tailgate protector.

LIFETIME WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90-day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.

INSTRUCTION #355- JUNE 2004