


**BRACKET KIT  
ACC (Adaptive Cruise Control)**

**PARTS LIST:**

|    |                                   |
|----|-----------------------------------|
| 1  | ACC Sensor Main Bracket           |
| 1  | ACC Adapter Bracket               |
| 1  | Foam Gasket                       |
| 1  | Plastic Sensor Cover              |
| 2  | 8-1.25mm x 25mm Button Head Bolts |
| 4  | 8mm x 24mm x 2mm Flat Washers     |
| 2  | 8mm Lock Washers                  |
| 2  | 8mm Hex Nuts                      |
| 7  | 6-1.0mm x 25mm Button Head Bolts  |
| 10 | 6mm x 18mm x 2mm Flat Washers     |
| 7  | 6mm Lock Washers                  |
| 7  | 6mm Hex Nuts                      |
| 1  | 5mm Wrench                        |
| 1  | 4mm Wrench                        |



**PROCEDURE:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**

1. Remove the (2) rubber plugs from the top of the driver/left side of the Bumper, **(Figure 1)**.
2. Select the ACC Relocation Bracket and Foam Seal. Attach the Seal to the bottom of the Bracket, **(Figure 1)**.
3. Attach the Mounting Bracket to the top of the Bumper with the included (2) 8mm x 25mm Button Head Bolts, (4) 8mm Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Nuts, **(Figure 1)**.
4. Select the ACC (adaptive cruise control) sensor removed from the factory bumper. Note the design of the sensor.

**Vehicles with early style ACC with tabs on ends:**


- a. Select the ACC Plastic Cover, **(Figure 2)**. Insert (3) 6mm x 25mm Button Head Bolts through the Plastic Cover, the Bracket and out through the ACC sensor. Secure with (3) 6mm Flat Washers, (3) 6mm Lock Washers and (3) 6mm Hex Nuts.

**Vehicles with late style ACC with tabs on top and bottom:**

- a. Select the Mounting Bracket Adapter Plate, **(Figure 3)**.
  - b. Attach the ACC sensor to the back of the Adapter with the included (3) 6mm x 25mm Button Head Bolts, (6) 6mm Flat Washers, (3) 6mm Lock Washers and (3) 6mm Hex Nuts, **(Figure 3)**.
  - c. Attach the ACC sensor and Adapter Plate to the back of the Bracket. Line up the Plastic Cover with the front of the Bracket. Insert (3) 6mm x 25mm Button Head Bolts through the ACC Plastic Cover, the Bracket, the Adapter Plate, **(Figure 4)**. Secure with (3) 6mm Flat Washers, (3) 6mm Lock Washers and (3) 6mm Hex Nuts.
5. Plug sensor wiring harness into sensor.
  6. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Bracket.


**BRACKET KIT  
ACC (Adaptive Cruise Control)**



- (2) 8mm x 25mm Button Head Bolts
- (4) 8mm Flat Washers
- (2) 8mm Lock Washers
- (2) 8mm Hex Nuts


**(Fig 1) Remove rubber plugs from top of Bumper. Attach Bracket to top of Bumper**

- (3) 6mm x 25mm Button Head Bolts
- (6) 6mm Flat Washers
- (3) 6mm Lock Washers
- (3) 6mm Hex Nuts




**(Fig 3) Attach late style Sensor to Adapter Bracket**

- (3) 6mm x 25mm Button Head Bolts
- (3) 6mm Flat Washers
- (3) 6mm Lock Washers
- (3) 6mm Hex Nuts



**(Fig 2) Attach Plastic Sensor Cover to front of Bracket and early sensor to back of Bracket**

- (3) 6mm x 25mm Button Head Bolts
- (3) 6mm Flat Washers
- (3) 6mm Lock Washers
- (3) 6mm Hex Nuts



**(Fig 4) Attach late style Sensor w-Adapter Bracket to back of Mounting Bracket**