




09-14 F150 Super Cab Aluminum Running Boards

PARTS LIST:

2	Running Boards	16	8mm x 24mm OD x 2mm STD Flat Washers
4	Universal Brackets	16	8mm Lock Washers
4	Plastic Cover for Brackets	8	8mm Hex Nuts
8	Plastic Clips for Covers	8	6mm x 20mm "T" Bolts
8	8mm Deep Clip Nuts	8	6mm x 22mm x 2mm Flat Washers
8	8-1.25mm x 30mm Hex Bolts	8	6mm Lock Washers
8	8-1.25mm x 25mm Hex Bolts	8	6 mm Hex Nuts
8	8mm x 28mm OD x 3mm Large Flat Washers		




PROCEDURE:

- REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**
- Starting on the passenger/right side of the vehicle, locate the (2) holes in the bottom of the body panel, (pinch weld), toward the front tire, **(Figure 1)**. Next locate the rectangular opening and (2) small holes in the inner body panel directly above the holes in the pinch weld, **(Figures 1 & 2)**. **NOTE:** The holes in the inner panel may be covered with sealing tape or insulation.
- Slide (1) 8mm Clip Nut into the rectangular opening with the nut towards the inside. Line up the threaded nut on the clip with the round hole, **(Figure 2)**. Repeat to install the 2nd 8mm Clip Nut in remaining hole location.
- Select (1) Universal Mounting Bracket. Attach the Bracket to the (2) Clip Nuts with the included (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm x 28mm Large Flat Washers, **(Figures 3 & 5)**. **NOTE:** Depending on model and year, the brake cable on the driver side front may be run on the inside or outside of the Bracket. Do not tighten hardware at this time.
- Align the bottom holes in the front Bracket with the (2) holes in the pinch weld. Bolt the Bracket to the pinch weld using the included (2) 8mm x 25mm Hex Bolts, (4) 8mm STD Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Nuts, **(Figures 4 & 5)**. **NOTE:** Insert the bolts up from the bottom of the pinch weld and through the Bracket.
- Select (1) Plastic Cover and (2) Cover Clips. Slide the Cover over the top of the Bracket and line up the (2) holes in the cover with the holes in the Bracket, **(Figures 6 & 7)**. Insert the Cover Clips into the holes. Push the center pin in on each clip until it is flush against the outer ring to expand the clip.
- Continue along the cab toward the rear and locate the last (2) mounting holes in the pinch weld at the back of the cab, **(Figure 1)**. Repeat **Steps 2—6** for rear Bracket and Cover installation.


8. Select (1) Running Board and (4) 6mm T-Bolts. Locate the opening in the end of each of the channels in the bottom of the Running Board. Slide (2) T-Bolts into each channel, **(Figure 8)**.
9. With assistance, carefully position the Running Board onto the (2) Mounting Brackets. Lift the Running Board up and slide the T-Bolts along the channels to line up with the Brackets. **IMPORTANT:** Do not slide the Running Board on the Brackets, (front to back or rotate), or the finish on the Running Board may be damaged.
10. Line up the front of the Running Board approximately 2" back, (or locate as desired), from the front wheel opening. Attach the Running Board to the Brackets with (4) 6mm Flat Washers, (4) 6mm Lock Washers and (4) 6mm Hex Nuts, **(Figure 9)**. Do not tighten hardware at this time.
11. Level and adjust the Running Board and tighten all hardware.
12. Repeat **Steps 2—11** for driver/left Running Board installation.
13. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Running Board.


Passenger/right Side Installation Pictured




(Fig 1) Passenger/right inner body panel illustrated



(Fig 2) Slide 8mm Clip Nuts over holes




(Fig 3) Passenger/right mounting Bracket




(Fig 4) Passenger/right mounting Bracket


Passenger/right Side Installation Pictured




(Fig 5) Passenger/right front Bracket installed



(Fig 6) Push center of pin into Clip to expand in Bracket




(Fig 7) Cover installed on passenger/right front Bracket



(Fig 8) Slide (2) T-Bolts into each slot

- (2) 6mm Flat Washers
- (2) 6mm Lock Washers
- (2) 6mm Hex Nuts



(Fig 9) Attach T-Bolts in Running Board to Bracket

